


































LAY5 Indicator Series

Push button& Indicator	Description	Contact	Circuit	Color	Type
LAY5-BA21					
	Even button spring return	N/O		White	LAY5-BA11
				Black	LAY5-BA21
				Green	LAY5-BA31
				Yellow	LAY5-BA51
				Blue	LAY5-BA61
LAY5-BA42					
	Even button spring return	N/C		Red	LAY5-BA42
LAY5-BA55					
	Even button spring return	N/O + N/C		White	LAY5-BA15
				Black	LAY5-BA25
				Green	LAY5-BA35
				Yellow	LAY5-BA55
				Blue	AY5-BA65
		N/O + N/C		Red	LAY5-BA45
LAY5-BP31					
	Even button (Atansparent silica gel cover) Unmarked IP65	N/O		White	LAY5-BP11
				Black	LAY5-BP21
				Green	LAY5-BP31
				Yellow	LAY5-BP51
				Blue	LAY5-BP61
LAY5-BP42					
	Even button (Atansparent silica gel cover) Unmarked IP65	N/C		Red	LAY5-BP42

Push button& Indicator	Description	Contact	Circuit	Color	Type
LAY5-BA3311					
	Even button spring return With synbol logo	N/O		■Green	LAY5-BA3311
				■Green	LAY5-BA3361
LAY5-BA3341					
	Even button spring return With synbol logo	N/O		Black or	LAY5-BA3351
				White for↓	LAY5-BA3341
LAY5-BA4342					
	Even button spring return With synbol logo	N/C		●Red	LAY5-BA4322
				●Red stop	LAY5-BA4342
LAY5-BL31					
	Even button spring return With synbol logo	N/O		Black	AY5-BL21
				■Green	LAY5-BL31
				■Yellow	LAY5-BL51
				■Blue	LAY5-BL61
LAY5-BL3311					
	Even button spring return With synbol logo	N/O		■Green	LAY5-BL3311
				■Green	LAY5-BL3361
LAY5-BL3341					
	Even button spring return With synbol logo	N/O		Black or	LAY5-BL3341
				White for↓	LAY5-BL3351

Push button& Indicator	Description	Contact	Circuit	Color	Type
LAY5-BC42					
	Mushroom head	N/O		Black Φ40	LAY5-BC21
				Green Φ40	LAY5-BC31
		N/C		Red Φ40	LAY5-BC42
LAY5-BS42					
	Turn to release	N/O		Red Φ30	LAY5-BS442
		N/C		Red Φ40	LAY5-BS542
		N/O+N/C		Red Φ60	LAY5-BS642
LAY5-BT42					
	Push-pull Red	N/C		Green Φ40	LAY5-BT42
				Black Φ60	LAY5-BX42
LAY5-BS142					
	Key release (Key n° 445)	N/C		Red Φ30	LAY5-BS742
				Red Φ30	LAY5-BS142
				Red Φ40	LAY5-BS242
	Turn to release	N/O + N/C		Red Φ40	LAY5-BS8445
Key release (Key n° 445)	Red			LAY5-BS9445	